

ANSWER Adjustable Stems

Required Tools:

- Torque Wrench
- 5mm Allen Attachment
- 6mm Allen Wrench

Instructions:

1. Choose your desired stem length. (Thin side of insert toward the back of the bike is the shorter option.)
2. Slide stem with insert over the steer tube and install spacers to fill the rest of the steer tube, then install top cap.
3. With everything on the steer tube snug, alternate tightening between the top and bottom steer tube pinch bolts on the stem using a 6mm Allen wrench until both bolts are securely tightened.
4. Center your handlebars contact area in the stem and hand tighten the 4 bolts until handlebars stay in place.
5. Please refer to the owner's manual of your specific handlebars to determine the exact torque specification.
6. Using the torque spec for your specific handlebars, alternate tightening the 4 bolts in an even, cross-pattern tightening technique until all 4 bolts are tightened to specification. Double check that the faceplate on the stem is level on the front and back side of the handlebars. If it is not, remove the 4 bolts and repeat step 6 while ensuring the faceplate is level.
7. Always check to ensure that all bolts and screws are securely tightened while performing routine bike maintenance.