

ANSWER Mini Gear

Required Tools:

- 3mm Allen wrench
- Grease

Instructions:

- 1 Grease the inside of the square hole on sprocket as well as the outside of the square flange on the drive-side crank arm.
- 2 Line the square hole on the mini sprocket up to the crank arm with the square flange on the crank arm.
- 3 Using the bolts supplied with the cranks, tighten the bolts equally in a rotating crossing pattern using a 3mm allen wrench until the gear becomes flat against the back of the crank arm.
- 4 Snug all four bolts completely tight.
- 5 Please ensure tightness of all bolts and screws while performing your regular bike maintenance.