

ANSWER Alumilite Threaded Cog

Required Tools:

- Chain Whip
- 28mm Flat/thin Wrench
- Grease

Installation Instructions:

- 1 Generously grease the threads on your hub's driver as well as the threads on the cog. This step is very important. Without grease, removal of the cog will become much more difficult.
- 2 With the size marking on the cog facing away from the hub, carefully thread the cog clockwise onto the driver until completely snug. There is no need to over-tighten the cog as it is designed to tighten as the chain rotates the cog once it is installed.
- 3 Please ensure tightness of all bolts and screws while performing your regular bike maintenance.

Removal Instructions:

- 1 Place the 28mm flat wrench onto the driver in-between the hub body and the backside of the cog. This will be used to stop the driver from rotating.
- 2 Position the chain whip on the cog to rotate it counter-clockwise.
- 3 Rotate the chain whip counter-clockwise while holding the 28mm wrench still to unthread the cog.