

ANSWER Grips

Required Tools:

- 2.5mm allen wrench

Instructions:

- 1 Remove existing grips, if necessary.
- 2 Ensure the grip ends are completely on the grip rubber.
- 3 Slide one grip onto the handlebar completely.
- 4 Using a 2.5mm allen wrench, tighten bolts to the torque spec for your specific handlebar. **Please note that your handlebars have a specific torque rating.** You can easily destroy your handlebars if tightened too tight. Please refer to your handlebar owner's manual for that torque specification.
- 5 Repeat steps 3 and 4 for the second grip.
- 6 Please ensure tightness of all bolts and screws while performing your regular bike maintenance.